

C4 & HYDRO:EVOLVED

→ GRAPHICAL USER INTERFACE ←
MANUAL

VERSION 2.3



Document History

Date	Version	Summary of Changes
August 6, 2024	2.3	Updated the <i>Dynamic Security</i> section.
May 20, 2024	2.2	Added the <i>REPLAY</i> section.
March 14, 2024	2.1	Updated document presentation. Updated the <i>Connect to GUI</i> subsection. Added the <i>Software Download Pre-requisites</i> section. Added the <i>SECURITY</i> section. Added the <i>USERS</i> section. Added a List of Abbreviations.
November 28, 2022	2	Complete overhaul of the document. Updated all the sections. Added the <i>Dynamic Security</i> section. Updated the <i>Update Files</i> section. Added the <i>System Update</i> section.
November 4, 2020	1.4	Added information from the <i>C4 GUI Startup Guide</i> . Added <i>Backup Param</i> section. Updated <i>System</i> section with new figures and procedures. Updated <i>Parking</i> section with new figures and procedures. Added Success and Warning popup messages.
February 20, 2020	1.3	Updated <i>Parking</i> section to show Calendar and Rules for specific dates and times. Added <i>About</i> section. Deleted <i>Security</i> section. Deleted <i>Backup Param</i> section. Replaced all screenshots to include the ABOUT in the Navbar.
November 27, 2019	1.2	Updated cover image. Updated format. Replaced all screenshots and added descriptions for fields and buttons.
January 16, 2019	1.1	Updated MONITORING, NAVBAR, PARAMETER (S-Curve, PI Label) and SYSTEM (Real Time Clock).
January 11, 2019	1.0	Initial Release

Table of Contents

1	Introduction	1
1.1	Wire the DAD Unit to GUI	1
1.2	Connect to GUI.....	1
2	NAVBAR	3
3	MONITORING.....	5
4	FAULTS	8
5	ALARMS	10
6	PARAMETER.....	12
6.1	Manual Edit	12
6.2	Speeds	14
6.3	Brakes.....	16
6.4	Fire.....	18
6.5	Doors.....	20
6.6	S-Curve	22
6.6.1	NORMAL PROFILE	25
6.6.2	INSPECTION PROFILE	27
6.6.3	SHORT PROFILE.....	29
6.6.4	EMERGENCY PROFILE	31
6.7	PI Labels.....	33
7	CAR CALLS.....	36
8	HALL CALLS	38
9	SYSTEM	40
9.1	Software Download.....	40
9.1.1	Software Download Pre-requisites	40
9.2	Backup Param	55
9.3	Restore Param.....	58
9.4	Update Files	61
9.4.1	UPDATE FILES.....	62
9.4.2	UPDATE CONFIG	66
9.5	Real Time Clock	69
9.6	System Update.....	71

10	I/O	73
10.1	Machine Room	73
10.2	Cartop	75
10.3	COP	77
10.4	Risers	80
10.5	Expansions	83
11	PARKING	86
11.1	Calendar.....	86
11.2	Rules	87
12	DYNAMIC SECURITY	91
12.1	Rules	91
13	SECURITY	96
14	REPLAY	98
14.1	List & Configuration	98
15	USERS	109
16	ABOUT	112
	List of Abbreviations	114

List of Figures

- Figure 1: DAD Connector Cable 1
- Figure 2: GUI Login Page 2
- Figure 3: NAVBAR Traction 3
- Figure 4: NAVBAR Hydro..... 4
- Figure 5: MONITORING Panel..... 5
- Figure 6: MONITORING Panel: FAULTED CAR..... 6
- Figure 7: MONITORING Panel - Car Status..... 7
- Figure 8: FAULTS Panel 8
- Figure 9: ALARMS Panel 10
- Figure 10: PARAMETER Panel - Manual Edit..... 12
- Figure 11: PARAMETER Panel - Manual Edit UPDATE 14
- Figure 12: PARAMETER Panel - Speeds (Traction Configuration) 14
- Figure 13: PARAMETER Panel - Speeds (Hydro Configuration) 15
- Figure 14: PARAMETER Panel - Speeds SAVE 16
- Figure 15: PARAMETER Panel - Brakes..... 16
- Figure 16: PARAMETER Panel - Brakes SAVE 17
- Figure 17: PARAMETER Panel - Fire..... 18
- Figure 18: PARAMETER Panel - Fire SAVE 20
- Figure 19: PARAMETER Panel - Doors 20
- Figure 20: PARAMETER Panel - Doors SAVE 22
- Figure 21: PARAMETER Panel - Motion-Curve (Hydro Configuration) 23
- Figure 22: PARAMETER Panel - Motion-Curve SAVE I (Hydro Configuration) 24
- Figure 23: PARAMETER Panel - Motion-Curve SAVE II (Hydro Configuration) 25
- Figure 24: PARAMETER Panel - S-Curve NORMAL PROFILE 26
- Figure 25: PARAMETER Panel - S-Curve NORMAL PROFILE SAVE 27
- Figure 26: PARAMETER Panel - S-Curve INSPECTION PROFILE 28
- Figure 27: PARAMETER Panel - S-Curve INSPECTION PROFILE SAVE 29
- Figure 28: PARAMETER Panel - S-Curve SHORT PROFILE..... 29
- Figure 29: PARAMETER Panel - S-Curve SHORT PROFILE: SAVE 31
- Figure 30: PARAMETER Panel - S-Curve EMERGENCY PROFILE..... 31
- Figure 31: PARAMETER Panel - S-Curve EMERGENCY PROFILE SAVE 33
- Figure 32: PARAMETER Panel - PI Labels 34
- Figure 33: PARAMETER Panel - PI Labels SAVE 35
- Figure 34: CAR CALLS Panel 36
- Figure 35: CAR CALLS Panel ACTIVE CAR CALL..... 37
- Figure 36: HALL CALLS Panel..... 38
- Figure 37: HALL CALLS Panel ACTIVE HALL CALL..... 39
- Figure 38: SYSTEM PANEL - Software Download 41

Figure 39: MR Board – ERROR.....	42
Figure 40: SYSTEM Panel - Software Download CHOOSE FILE	43
Figure 41: SYSTEM Panel - Software Download UPLOAD.....	44
Figure 42: SYSTEM Panel - Software Download CHECKING STATUS	44
Figure 43: SYSTEM Panel - Software Download WARNING	45
Figure 44: SYSTEM Panel - Software Download UPDATE (.sbf)	45
Figure 45: SYSTEM Panel - Software Download UPDATE (.zip).....	46
Figure 46: SYSTEM Panel - Software Download UPDATE (MR, CT, COP).....	47
Figure 47: SYSTEM Panel - Software Download SHOW DETAILS (MR, CT, COP).....	48
Figure 48: MR board - SOFTWARE DOWNLOAD PROGRESS.....	48
Figure 49: SYSTEM Panel - Software Download RISER UPDATE (.sbf).....	49
Figure 50: SYSTEM Panel - Software Download RISER UPDATE ALL	50
Figure 51: SYSTEM Panel - Software Download RISER SHOW DETAILS.....	51
Figure 52: SYSTEM Panel - Software Download (MR, CT, COP) SUCCESS.....	52
Figure 53: SYSTEM Panel - Software Download RISER SUCCESS.....	52
Figure 54: SYSTEM Panel - Software Download DONE.....	53
Figure 55: SYSTEM Panel - Software Download Update Completed	54
Figure 56: SYSTEM Panel – Software Download WARNING	55
Figure 57: SYSTEM Panel - Backup Param.....	55
Figure 58: SYSTEM Panel - Backup Param CAR OFFLINE	56
Figure 59: SYSTEM Panel - Backup Param START BACKUP	57
Figure 60: SYSTEM Panel - Backup Param DOWNLOAD BACKUP	57
Figure 61: SYSTEM Panel - Restore Param	58
Figure 62: SYSTEM Panel - Restore Param UPLOAD FILE	59
Figure 63: SYSTEM Panel - Restore Param START RESTORE.....	59
Figure 64: SYSTEM Panel - Restore Param WARNING	60
Figure 65: SYSTEM Panel - Restore Param RESTORE PROGRESS	60
Figure 66: SYSTEM Panel - Restore Param RESTORE COMPLETED I.....	61
Figure 67: SYSTEM Panel - Restore Param RESTORE COMPLETED II.....	61
Figure 68: SYSTEM Panel - Update Files [FILES]	62
Figure 69: SYSTEM Panel - Update Files [FILES: CHOOSE FILE (From USB inserted into DAD)]	63
Figure 70: SYSTEM Panel - Update Files [FILES: UPLOAD & UPDATE (From your Device)]	63
Figure 71: SYSTEM Panel - Update Files [FILES: UPLOAD & UPDATE (From USB inserted into DAD)]	64
Figure 72: SYSTEM Panel - Update Files [FILES: LOADING].....	64
Figure 73: SYSTEM Panel - Update Files [FILES: SUCCESS]	65
Figure 74: SYSTEM Panel - Update Files [FILES: UPLOADED LIST OF FILES]	65
Figure 75: SYSTEM Panel - Update Files [FILES: INVALID FILE]	66
Figure 76: SYSTEM Panel - Update Files [CONFIG].....	66
Figure 77: SYSTEM Panel - Update Files [CONFIG: UPDATE CONFIG].....	67
Figure 78: SYSTEM Panel - Update Files [CONFIG: SYNC NEW CONFIG].....	68
Figure 79: SYSTEM Panel - Update Files [CONFIG: SUCCESS].....	68

Figure 80: SYSTEM– Update Config SYSTEM RELOAD	69
Figure 81: SYSTEM Panel - Real Time Clock.....	69
Figure 82: SYSTEM Panel - Real Time Clock SYSTEM RELOAD.....	70
Figure 83: MONIROTING Panel Landing Page.....	71
Figure 84: SYSTEM Panel - System Update	72
Figure 85: I/O Panel - Machine Room	73
Figure 86: I/O Panel - Machine Room SAVE	74
Figure 87: I/O Panel – Cartop.....	75
Figure 88: I/O Panel - Cartop SAVE.....	77
Figure 89: I/O Panel - COP.....	78
Figure 90: I/O Panel – COP SAVE.....	80
Figure 91: I/O Panel – Risers.....	81
Figure 92: I/O Panel - Risers SAVE.....	82
Figure 93: I/O Panel – Expansions	83
Figure 94: I/O Panel - Expansions SELECT EXPANSION BOARD	84
Figure 95: I/O Panel – Expansions SAVE.....	85
Figure 96: PARKING Panel - Calendar	86
Figure 97: PARKING Panel.....	87
Figure 98: PARKING Panel - Rules.....	88
Figure 99: PARKING Panel – Rules CREATE RULE [Car-specific popup].....	89
Figure 100: PARKING Panel - Rules: CREATE RULE [Floor-specific popup]	89
Figure 101: DYNAMIC SECURITY Panel	91
Figure 102: DYNAMIC SECURITY Panel – Rules (I).....	92
Figure 103: DYNAMIC SECURITY Panel – Rules (II).....	92
Figure 104: DYNAMIC SECURITY – Rules CREATE RULE popup	93
Figure 105: Activating a Rule	94
Figure 106: Secured Floors Display [Hall Calls]	95
Figure 107: Secured Floors Display [Car Calls].....	95
Figure 108: SECURITY Panel	96
Figure 109: SECURITY Panel Active.....	97
Figure 110: REPLAY Panel – List [Default: no events].....	98
Figure 111: REPLAY Panel - Configuration [Faults: default state].....	99
Figure 112: REPLAY Panel- Configuration [Alarms: default state].....	99
Figure 113: REPLAY Panel- Configuration [Faults: selected state].....	100
Figure 114: REPLAY Panel- Configuration [Alarms: selected state]	100
Figure 115: REPLAY Panel- Configuration [Success popup]	101
Figure 116: REPLAY Panel – Configuration SYSTEM RELOAD	101
Figure 117: REPLAY Panel - List [Event tracking].....	102
Figure 118: REPLAY Panel – List [Filter applied: Faults]	102
Figure 119: REPLAY Panel – List [Filter applied: Alarms].....	103
Figure 120: REPLAY Panel – List [Filter applied: Car position].....	103

Figure 121: REPLAY Panel – List [Filter applied: Car speed].....	104
Figure 122: REPLAY Panel - List [Car position and car speed]	104
Figure 123: REPLAY Panel - List [Car data popup].....	105
Figure 124: REPLAY Panel - List [All inputs statuses].....	105
Figure 125: REPLAY Panel - List [All outputs statuses]	106
Figure 126: REPLAY Panel – List [Shorter time intervals]	106
Figure 127: REPLAY Panel- List [Download graph].....	107
Figure 128: REPLAY Panel – List [EVENTS: Multiple cars Q8]	107
Figure 129: REPLAY Panel – List [EVENTS: Multiple cars Q5]	108
Figure 130: USERS Panel - Create User	109
Figure 131: USERS Panel - Create User USERNAME VALIDATION	109
Figure 132: USERS Panel - Create User PASSWORD VALIDATION.....	110
Figure 133: USERS Panel - All Users	110
Figure 134: USERS Panel - Change Password.....	111
Figure 135: ABOUT Panel: TRACTION JOB	112
Figure 136: ABOUT Panel: HYDRO JOB.....	112

List of Tables

Table 1: Wiring for the DAD Connector Cable	1
Table 2: MONITORING Panel.....	6
Table 3: MONITORING Panel - Car Status.....	7
Table 4: FAULTS Panel	8
Table 5: ALARMS Panel	10
Table 6: PARAMETER Panel - Manual Edit.....	12
Table 7: PARAMETER Panel - Speeds.....	15
Table 8: PARAMETER Panel - Brakes	17
Table 9. PARAMETER Panel - Fire	18
Table 10: PARAMETER Panel - Doors	21
Table 11: PARAMETER Panel - S-Curve NORMAL PROFILE.....	26
Table 12: PARAMETER Panel - S-Curve INSPECTION PROFILE.....	28
Table 13: PARAMETER Panel - S-Curve SHORT PROFILE.....	29
Table 14: PARAMETER Panel - S-Curve EMERGENCY PROFILE.....	31
Table 15.:PARAMETER Panel - PI Labels.....	34
Table 16: CAR CALLS Panel	36
Table 17: HALL CALLS Panel.....	38
Table 18: SYSTEM Panel - Software Download	41
Table 19: MR board - SOFTWARE DOWNLOAD PROGRESS.....	42
Table 20: SYSTEM Panel - Backup Param	56
Table 21: SYSTEM Panel - Restore Param	58
Table 22: SYSTEM Panel - Update Files [FILES]	62
Table 23: SYSTEM Panel - Update Files [CONFIG]	67
Table 24: SYSTEM Panel - Real Time Clock.....	70
Table 25: SYSTEM Panel - System Update	72
Table 26: I/O Panel - Machine Room	73
Table 27: I/O Panel - Cartop	76
Table 28: I/O Panel - COP	78
Table 29: I/O Panel - Risers	81
Table 30: I/O Panel - Expansions.....	83
Table 31: PARKING Panel - Calendar	87
Table 32: PARKING Panel - Rules	88
Table 33: PARKING Panel - Rules: CREATE RULE popup	90
Table 34: DYNAMIC SECURITY Panel - Rules	92
Table 35: DYNAMIC SECURITY Panel - Rules CREATE RULE popup	93
Table 36: ABOUT Panel.....	113

Page intentionally left blank.

1 Introduction

The C4 Controller uses a Data Acquisition Device (DAD) to communicate with the Graphical User Interface (GUI). Users can set the C4 parameters and settings through GUI.

1.1 Wire the DAD Unit to GUI

Some C4 controllers do not have the DAD connector wired.

If the controller does not already have the cable wired, wire the connector as shown in the figure below:




Figure 1: DAD Connector Cable

The table below lists the Wiring for the DAD Connector Cable.

Table 1: Wiring for the DAD Connector Cable

PIN	Wire Color	Signal
1	White/Blue	REF
2	Blue	24 VDC
3	Twisted Pair – White	GN-
8	Twisted Pair – Blue	GN+

1.2 Connect to GUI

When connecting the DAD unit to GUI, only one DAD Unit per group can be powered up.

Perform the following steps to connect to GUI:

1. Power up the controller.

NOTE: the DAD Fault and Heartbeat (HB) LEDs start flashing, and the HB turns green when ready.

2. Connect to GUI using a Wi-Fi laptop or tablet.

NOTE: if you are using Windows 10, go to the NETWORK & INTERNET SETTINGS (🌐) menu option on the bottom right of the main desktop window.

3. Select the Wi-Fi Connection:

- i. **For Traction configuration:** select the 'C4 [Job_Site_Name]' Wi-Fi connection.
- ii. **For Hydraulic configuration:** select the 'Evolved [Job_Site_Name]' Wi-Fi connection.

4. Enter the password: SmartriseMRM.

5. Click on CONNECT.

6. Click on OK.

NOTE: the connection shows: No internet, secured.

7. Open a web browser (preferably Google Chrome or Firefox).

8. Type '192.168.4.1' in the address bar.

NOTE: the user will automatically be redirected to the GUI login page.




Figure 2: GUI Login Page

2 NAVBAR

The NAVBAR is a set of menu options the user can choose from to navigate between menu panels. The NAVBAR is displayed on the left side of every panel.




Figure 3: NAVBAR Traction





Figure 4: NAVBAR Hydro

3 MONITORING

The MONITORING panel displays real time data from cars within the same group. Each car displays the following information:

- Car Label
- Current Floor
- Destination
- Mode Operation



The screenshot shows the SMARTRISE MONITORING panel. The interface includes a top navigation bar with the SMARTRISE logo, the user role 'admin', and a 'Logout' link. A search bar contains the text 'MONITORING'. A left sidebar lists various system components: FAULTS, ALARMS, PARAMETER, CAR CALLS, HALL CALLS, SYSTEM, I/O, PARKING, DYNAMIC SECURITY, SECURITY, USERS, and ABOUT. The main content area displays a table with 8 rows, each representing a car. The table columns are Car Label, CURRENT FLOOR, DESTINATION, and MODE. Car1 is highlighted in red and has a current floor of 20 and a destination of 20, with a mode of Normal. Car2 has a current floor of 0 and a destination of 0, with a mode of Normal. Cars 3 through 8 all have a current floor of 0 and a destination of 0, with a mode of Offline.

Car Label	CURRENT FLOOR	DESTINATION	MODE
Car1	20	20	Normal
Car2	0	0	Normal
Car3	0	0	Offline
Car4	0	0	Offline
Car5	0	0	Offline
Car6	0	0	Offline
Car7	0	0	Offline
Car8	0	0	Offline

Figure 5: MONITORING Panel

If a car is faulted, the car DIV is highlighted in red as seen in the image below.




Figure 6: MONITORING Panel: FAULTED CAR

The table below lists the description of the MONITORING Panel.

Table 2: MONITORING Panel

Field	Description
CAR LABEL	Displays the car label
CURRENT FLOOR	Displays the car’s current location
DESTINATION	If applicable, displays the next destination landing
MODE	Displays the mode of operation
FAULTED	If faulted, displays the fault number and name

When the user clicks anywhere inside a specific car record, the MONITORING Panel displays the status of that particular car.





Figure 7: MONITORING Panel - Car Status

Table 3: MONITORING Panel - Car Status

Field	Description
CURRENT FLOOR	Displays the car’s current location
DESTINATION	Displays the next destination landing (if any)
MODE	Displays the mode of operation
FRONT DOOR	Displays the front door status (open, opening, close, closing, nudge...)
REAR DOOR	Displays the rear door status (open, opening, close, closing, nudge...)
SPEED	Displays the speed of the car
POSITION	Displays the position of the car
Buttons	
	Allows the user to return to the MONITORING Panel

4 FAULTS

The FAULTS Panel displays a log of the faults triggered by any car within a group.






Figure 8: FAULTS Panel

The table below lists the description of the FAULTS Panel.

Table 4: FAULTS Panel

Field	Description
CAR All 1 2	Allows the user to select the faults for all cars or a specific car
CAR	Displays the car label of the car with the fault
FAULT	Displays the fault's number

NAME	Displays the fault's name
DESCRIPTION	Displays the fault's description
SOLUTION	Displays the fault's potential solutions
DATE	Displays the fault's date & time
Buttons	
	Allows the user to clear all faults
	Allows the user to download the faults list

Perform the following steps to clear the faults list:

1. Go to the FAULTS Panel.
2. Click on CLEAR FAULTS.

NOTE: all faults will be cleared from the list.

Perform the following steps to download the faults list:

1. Go to the FAULTS Panel.
2. Click on DOWNLOAD FAULTS.

NOTE: the “faults.csv” file will be downloaded into the Downloads folder on the user’s device by default. The user can also select the location of the download.

5 ALARMS

The ALARMS Panel displays a log of the alarms triggered by any car within a group.

Car	Floor Label	Alarm	Name	Description	Solution	Date
1	20	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 05:28:22
2	0	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 05:28:20
1	20	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 04:57:52
2	1	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 04:57:52
1	20	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 04:57:01
2	1	A1447	Shield COM RPI	Shield has not seen communication from the RPI in 5 seconds.	Check wiring of power and network lines.	Mar 04 2024 04:57:01
1	1	A1425	Fire Smoke Main	Fire phase 1 has been activated by the main smoke input.	Check the fire input and riser board status.	Feb 28 2024 08:20:45
1	4	A1438	RIS1 HB Offline	Riser 1 has reported communication loss with one of its hall boards.	Check the hall board status menu for a hall board reporting 0% communic...	Feb 28 2024 07:25:53
2	6	A1438	RIS1 HB Offline	Riser 1 has reported communication loss with one of its hall boards.	Check the hall board status menu for a hall board reporting 0% communic...	Feb 28 2024 07:25:41
2	1	A1438	RIS1 HB Offline	Riser 1 has reported communication loss with one of its hall boards.	Check the hall board status menu for a hall board reporting 0% communic...	Feb 28 2024 02:17:39
2	1	A1438	RIS1 HB Offline	Riser 1 has reported communication loss with one of its hall boards.	Check the hall board status menu for a hall board reporting 0% communic...	Feb 27 2024 10:24:14
2	1	A92	COPB WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 10:24:01
2	1	A90	CTB WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 10:24:01
2	1	A89	CTA WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 10:24:01
2	1	A91	COPA WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 10:24:01
2	1	A1540	FINAL Limit Bypassed	BFL or TFL is bypassed	Check if BFL/TFL is connected directly to 120VAC and wire it through ...	Feb 27 2024 10:24:00
2	1	A164	RIS2 POR Rst	Riser2 reporting a power-on reset error.	NA	Feb 27 2024 10:23:58
1	7	A1426	Fire Smoke Alt	Fire phase 1 has been activated by the alternate smoke input.	Check the fire input and riser board status.	Feb 27 2024 10:20:07
2	1	A92	COPB WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 09:49:24
2	1	A90	CTB WDT Disabled	Processor has started up with watchdog disabled.	Remove the WD jumper and restart the board to reenable.	Feb 27 2024 09:49:24




Number of alarms: 20

Page 1 2 3 > >>

Figure 9: ALARMS Panel

The table below lists the description of the ALARMS Panel.

Table 5: ALARMS Panel

Field	Description
	Allows the user to select the alarms for all cars or a specific car
CAR	Displays the car label of the car with the alarm
ALARM	Displays the alarm's number
NAME	Displays the alarm's name
DESCRIPTION	Displays the alarm's description
SOLUTION	Displays the alarm's potential solutions
DATE	Displays the alarm's date & time
Buttons	
	Allows the user to clear all alarms
	Allows the user to download the alarms list

Perform the following steps to clear the alarms list:

1. Go to the ALARMS Panel.
2. Click on CLEAR ALARMS.

NOTE: all alarms will be cleared from the list.

Perform the following steps to download the alarms list:

1. Go to the ALARMS Panel
2. Click on DOWNLOAD ALARMS

NOTE: the “alarms.csv” file is downloaded into the Downloads folder on the user’s device, and the user can also select the location of the download.

6 PARAMETER

The PARAMETER Panel allows the user to select parameters that are configured according to the job. For more information about setting the parameters, consult the *C4 User Manual* and *C4 Parameter List*.

6.1 Manual Edit

The Manual Edit subpanel allows the user to adjust a specific parameter to a specific car.

There are 5 types of parameters: 1-bit, 8-bit, 16-bit, 24-bit, and 32-bit.

Each type has its own set of parameters specified by an index.

Example: 01-0000 stands for Fire Main Use Rear Door and 01-0131 stands for Bypass Fire Service.

NOTE: the indexes are 0000 and 0131 and the type is 01.

The parameter can be adjusted based on the value entered for a selected car within the same group. When the user hits SEARCH, the parameter’s name (along with its current value), category, and option to adjust are displayed based on the user-entered value.

The user can enter a decimal number to adjust the corresponding parameter on the controller.







Figure 10: PARAMETER Panel - Manual Edit

The table below lists the description of the PARAMETER Panel - Manual Edit.

Table 6: PARAMETER Panel - Manual Edit

Field	Description
-------	-------------

	Allows the user to select the car label
Parameter Type	Allows the user to select the parameter type from the dropdown list
Parameter Index	Allows the user to enter the index of a specific parameter under the parameter type
The parameter type and index are pre-defined values. For the same parameter type and index, the value of a certain parameter may differ from one car to another.	
Adjust	Allows the user to enter or select the adjusted parameter based on the parameter type
Buttons	
	Allows the user to search for the parameter value according to the parameter type and index
	Allows the user to update the adjusted value for the parameter based on the user-entered value

Perform the following steps to manually edit the parameters for a particular car:

1. Turn on DIP A4 on the MR board.
2. From the PARAMETER Panel - Manual Edit, select the car label.
3. Select the Parameter Type from the dropdown list.
4. Enter the Parameter Index.
5. Click SEARCH.
6. Enter the adjusted value and click UPDATE.
 - If a valid adjustment has been made, a green UPDATE tag with a checkmark will be displayed.
7. **Optional:** turn off DIP A4.
 - DIP A4 will affect the functionality of PARAMETER Panel, SYSTEM Panel (Restore Param subpanel), and I/O Panel.
 - In case no modifications on the PARAMETERS are due.




Figure 11: PARAMETER Panel - Manual Edit UPDATE

6.2 Speeds

The speeds sub-panel allows the user to enter different speed parameters determined by the controller module.




Figure 12: PARAMETER Panel - Speeds (Traction Configuration)

The table below lists the description of the PARAMETER Panel - Speeds.

Table 7: PARAMETER Panel - Speeds

Field	Description
CAR 1 2	Allows the user to select the car label
CONTRACT SPEED	Allows the user to set the maximum elevator speed for which the job was configured
INSPECTION SPEED	Allows the user to set the speed at which the car operates in all inspection modes
LEARN SPEED	Allows the user to set the speed for the hoistway learn operation
TERMINAL SPEED	Allows the user to set the speed of the car while in inspection mode and within the configured soft limit distance of a terminal floor
LEVELING SPEED	Allows the user to set the automatic operation speed used when leveling to a floor
Buttons	
SAVE	Allows the user to save the set speeds parameters

NOTE: for the Hydro Jobs, only CONTRACT SPEED and INSPECTION SPEED are displayed.




Figure 13: PARAMETER Panel - Speeds (Hydro Configuration)

Perform the following steps to update the speeds parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - Speeds, select the car label.
3. Enter the new parameter value(s) and click SAVE.

- A green SAVE tag with a checkmark is displayed.




Figure 14: PARAMETER Panel - Speeds SAVE

6.3 Brakes

The Brakes subpanel allows the user to adjust the brake voltage used to control rollback.




Figure 15: PARAMETER Panel - Brakes

The table below lists the description of the PARAMETER Panel - Brakes.

Table 8: PARAMETER Panel - Brakes

Field	Description
CAR 1 2	Allows the user to select the car label
PICK VOLTAGE	Allows the user to set the pick voltage for opening the brakes
HOLD VOLTAGE	Allows the user to set a consistent voltage supplied to the brakes to keep them open
BRAKE PICK DELAY	Allows the user to set the time at which the brake is held at zero speed
RELEVEL VOTAGE	Allows the user to set the voltage at which the brake hardly lifts during releveling, allowing the sheave to rotate beneath the brake
Buttons	
SAVE	Allows the user to save the set brake parameters

Perform the following steps to update the brake voltage parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - Brakes, select the car label.
3. Enter the new brake voltage value(s) and click SAVE.
 - A green SAVE tag with a checkmark is displayed.




Figure 16: PARAMETER Panel - Brakes SAVE

6.4 Fire

The Fire subpanel allows the user to set parameters for the main and alternate fire recall floors.

The Fire subpanel contains 3 sections:

MAIN SMOKE: allows the user to choose the designated landing of the car in case smoke is detected in the main lobby.

MAIN RECALL: allows the user to choose the designated landing of a car in case of a fire.

ALTERNATE RECALL: allows the user to choose the designated alternate landing of a car in case there is a sign of a fire at the designated main recall floor.







Figure 17: PARAMETER Panel - Fire

The table below lists the description of the PARAMETER Panel - Fire.

Table 9. PARAMETER Panel - Fire

Field	Description
CAR 1 2	Allows the user to select the car label
MAIN SMOKE	
MAIN: USE ALTERNATE	Allows the user to select if the car travels to the main landing when smoke is detected

ALT: USE ALTERNATE	Allows the user to select if the car travels to the alternate landing when smoke is detected in the main lobby
FLASH FIRE HAT	Allows the user to select if the Flash Fire Hat symbol on the panel will flash when smoke is detected
SHUNT TRIP	Allows the user to select if the shunt output trips a breaker, cutting off the controller's main power in case of a fire in the main lobby
MAIN RECALL	
FLOOR (MAIN)	Allows the user to select the designated main landing when recalled
OPENING (MAIN)	Allows the user to select which door opens when recalled to the main designated landing
ALTERNATE RECALL	
FLOOR (ALT)	Allows the user to select the designated alternate landing when recalled
OPENING (ALT)	Allows the user to select which door opens when recalled to the alternate designated landing
Buttons	
	Allows the user to save the set main smoke parameters
	Allows the user to save the set main recall parameters
	Allows the user to save the set alternate recall parameters

Perform the following steps to update the smoke and recall parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - Fire, select the car label.
3. Select the new smoke and recall parameters from the dropdown list and click SAVE.
 - A green SAVE tag with a checkmark is displayed.




Figure 18: PARAMETER Panel - Fire SAVE

6.5 Doors

The Doors subpanel allows the user to configure the parameters for car door timings.

The timing of the doors to open, remain opened, close, or remain closed depends on the time of day and the purpose of the elevator.






Figure 19: PARAMETER Panel - Doors

The table below lists the description of the PARAMETER Panel - Doors.

Table 10: PARAMETER Panel - Doors

Field	Description
	Allows the user to select the car label
DOOR DWELL TIME	Allows the user to set the time for the doors to remain open while answering car calls
DOOR STUCK TIME	Allows the user to set the time limit for a door to completely open or close before faulting
DOOR NUDGE TIME	Allows the user to set the time for the doors trying to close after being held open for a certain amount of time. If set to zero, nudging is disabled.
DOOR DWELL HALL	Allows the user to set the time for the doors to remain open while answering hall calls
DOOR DWELL ADA	Allows the user to set the time for the doors to remain open while answering ADA calls
Buttons	
	Allows the user to save the set doors parameters

Perform the following steps to update the doors parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - Doors, select the car label.
3. Enter the new parameter value(s) and click SAVE.
 - A green SAVE tag with a checkmark is displayed.



Figure 20: PARAMETER Panel - Doors SAVE

6.6 S-Curve

The S-Curve subpanel allows the user to regulate the acceleration and speed to create a smooth transition without any abrupt jerking motion. It is reserved for traction jobs. For more information about the S-Curve and adjusting the parameters for all profiles, consult the *C4 User Manual*.

NOTE: for hydro jobs, a Motion-Curve is displayed (see Figure 21).

The following profiles are used under the S-Curve:

- NORMAL
- INSPECTION
- SHORT
- EMERGENCY




Figure 21: PARAMETER Panel - Motion-Curve (Hydro Configuration)




Figure 22: PARAMETER Panel - Motion-Curve SAVE I (Hydro Configuration)




Figure 23: PARAMETER Panel - Motion-Curve SAVE II (Hydro Configuration)

6.6.1 NORMAL PROFILE

The NORMAL PROFILE allows the user to adjust the parameters for all automatic operation runs that are longer than the minimum short profile distance, except for emergency power.




Figure 24: PARAMETER Panel - S-Curve NORMAL PROFILE

The table below lists the description of the PARAMETER Panel - S-Curve NORMAL PROFILE.

Table 11: PARAMETER Panel - S-Curve NORMAL PROFILE

Field	Description
CAR 1 2	Allows the user to select the car label
Acceleration	Allows the user to set the pace at which the car reaches constant speed on normal profile runs
Acceleration jerk in	Allows the user to set the transition from zero speed to full acceleration on normal profile runs
Acceleration jerk out	Allows the user to set the speed at which the profile transitions from maximum to zero acceleration (constant velocity) on normal profile runs
Deceleration	Allows the user to set the pace at which the car reaches leveling speed on normal profile runs
Deceleration jerk in	Allows the user to set the softness of the transition from constant velocity to deceleration on normal profile runs
Deceleration jerk out	Allows the user to set the softness of the transition from deceleration to leveling speed on normal profile runs
Leveling Distance	Allows the user to set the stabilized distance the elevator will travel before reaching the destination floor on normal profile runs
Buttons	
SAVE CHANGES	Allows the user to save the set normal profile parameters

Perform the following steps to update the normal profile parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - S-Curve NORMAL PROFILE, select the car label.
3. Slide the bar to the new parameter value(s) and click SAVE CHANGES.
 - A green checkmark is displayed.




Figure 25: PARAMETER Panel - S-Curve NORMAL PROFILE SAVE

6.6.2 INSPECTION PROFILE

The INSPECTION PROFILE allows the user to adjust the parameters for when the car is operating in Inspection mode.




Figure 26: PARAMETER Panel - S-Curve INSPECTION PROFILE

The table below lists the description of the PARAMETER Panel - S-Curve INSPECTION PROFILE.

Table 12: PARAMETER Panel - S-Curve INSPECTION PROFILE

Field	Description
CAR 1 2	Allows the user to select the car label
Acceleration	Allows the user to set the pace at which the car reaches constant speed on inspection profile runs
Acceleration jerk in	Allows the user to set the transition from zero speed to full acceleration on inspection profile runs
Acceleration jerk out	Allows the user to set the speed at which the profile transitions from maximum to zero acceleration (constant velocity) on inspection profile runs
Deceleration	Allows the user to set the pace at which the car reaches leveling speed on inspection profile runs
Buttons	
SAVE CHANGES	Allows the user to save the set inspection profile parameters

Perform the following steps to update the inspection profile parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - S-Curve INSPECTION PROFILE, select the car label.
3. Slide the bar to the new parameter value(s) and click SAVE CHANGES.
 - A green checkmark is displayed.




Figure 27: PARAMETER Panel - S-Curve INSPECTION PROFILE SAVE

6.6.3 SHORT PROFILE

The SHORT PROFILE allows the user to adjust the parameters for when the car is operating for the set minimum profile.





Figure 28: PARAMETER Panel - S-Curve SHORT PROFILE

The table below lists the description of the PARAMETER Panel - S-Curve SHORT PROFILE.

Table 13: PARAMETER Panel - S-Curve SHORT PROFILE

Field	Description
-------	-------------

CAR 1 2	Allows the user to select the car label
Acceleration	Allows the user to set the pace at which the car reaches constant speed on short profile runs
Acceleration jerk in	Allows the user to set the transition from zero speed to full acceleration on short profile runs
Acceleration jerk out	Allows the user to set the speed at which the profile transitions from maximum to zero acceleration (constant velocity) on short profile runs
Deceleration	Allows the user to set the pace at which the car reaches leveling speed on short profile runs
Deceleration jerk in	Allows the user to set the softness of the transition from constant velocity to deceleration on short profile runs
Deceleration jerk out	Allows the user to set the softness of the transition from deceleration to leveling speed on short profile runs
Leveling Distance	Allows the user to set the stabilized distance the elevator will travel before reaching the destination floor on short profile runs
Buttons	
	Allows the user to save the set short profile parameters

Perform the following steps to update the short profile parameters for a particular car:

1. Turn on DIP A4
2. From the PARAMETER Panel - S-Curve SHORT PROFILE, select the car label.
3. Slide the bar to the new parameter value(s) and click SAVE CHANGES.
 - A green checkmark is displayed.




Figure 29: PARAMETER Panel - S-Curve SHORT PROFILE: SAVE

6.6.4 EMERGENCY PROFILE

The EMERGENCY PROFILE allows the user to adjust the parameters for when the car is operating in Emergency mode.






Figure 30: PARAMETER Panel - S-Curve EMERGENCY PROFILE

The table below lists the description of the PARAMETER Panel - S-Curve EMERGENCY PROFILE.

Table 14: PARAMETER Panel - S-Curve EMERGENCY PROFILE

Field	Description
-------	-------------

	Allows the user to select the car label
Acceleration	Allows the user to set the pace at which the car reaches constant speed on emergency profile runs
Acceleration jerk in	Allows the user to set the transition from zero speed to full acceleration on emergency profile runs
Acceleration jerk out	Allows the user to set the speed at which the profile transitions from maximum to zero acceleration (constant velocity) on emergency profile runs
Deceleration	Allows the user to set the pace at which the car reaches leveling speed on emergency profile runs
Deceleration jerk in	Allows the user to set the softness of the transition from constant velocity to deceleration on emergency profile runs
Deceleration jerk out	Allows the user to set the softness of the transition from deceleration to leveling speed on emergency profile runs
Leveling Distance	Allows the user to set the stabilized distance the elevator will travel before reaching the destination floor on emergency profile runs
Buttons	
	Allows the user to save the set emergency profile parameters

Perform the following steps to update the emergency profile parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel - S-Curve EMERGENCY PROFILE, select the car label.
3. Slide the bar to the new parameter value(s) and click SAVE CHANGES.
 - A green checkmark is displayed.




Figure 31: PARAMETER Panel - S-Curve EMERGENCY PROFILE SAVE

6.7 PI Labels

The Position Indicator (PI) subpanel displays the assigned floor label for each floor.

The number of adjustable PIs available depends on the number of floors and openings of a job. The C4 System can support up to 96 floors.

NOTE: “PI” represents the floor label.

The user can adjust the label by entering numeric, alphanumeric, and special characters into the field. By default, the C4 system supports two characters per floor. Three-character PIs are possible by turning on a parameter (See the *C4 Parameter List*).




Figure 32: PARAMETER Panel - PI Labels

The table below lists the description of the PARAMETER Panel - PI Labels.

Table 15.:PARAMETER Panel - PI Labels

Field	Description
CAR 1 2	Allows the user to select the car label
PI_1 through PI_96	Allows the user to label any landing to a 3-digit alphanumeric or numeric configuration
COPY FROM	Allows the user to select a car number to copy PI Labels from
Buttons	
SAVE	Allows the user to save the set PI Label parameters made on the page

Perform the following steps to update the PI Label parameters for a particular car:

1. Turn on DIP A4.
2. From the PARAMETER Panel – PI Labels, select the car label.
3. If the car’s position:
 - i. is manually adjusted, go to Step 4
 - ii. is copied from another car, go to Step 5
4. Enter the new PI value (or values) for the individual car, then click on SAVE.
 - A green checkmark is displayed.
5. Click COPY FROM and select the car whose PI parameters are being copied, then click on SAVE.

- A green checkmark is displayed.




Figure 33: PARAMETER Panel - PI Labels SAVE

7 CAR CALLS

The CAR CALLS panel allows the user to initiate a Car Call from the system.

Each button on the screen represents to a floor. When the user presses a button, the controller registers a car call. If the system already has existing car calls, the corresponding button lights up.

NOTE: “R” indicates rear doors.




Figure 34: CAR CALLS Panel

The table below lists the description of the CAR CALLS Panel.

Table 16: CAR CALLS Panel

Field	Description
CAR 1 2	Allows the user to select the car label
Floor Number	Allows the user to select a floor

Perform the following steps to initiate a car call for a particular car:

1. From the CAR CALLS Panel, select the car label.
2. Click on the floor number.
 - The color of the active car call button turns blue.




Figure 35: CAR CALLS Panel ACTIVE CAR CALL

8 HALL CALLS

The HALL CALLS panel allows the user to initiate a Hall Call from the system. Each button on the screen represents a direction and floor. When the user presses a button, the controller registers a hall call in the chosen direction. If the system already has existing hall calls, the corresponding button direction lights up.

NOTE: “R” indicates rear doors.




Figure 36: HALL CALLS Panel

The table below lists the description of the HALL CALLS Panel.

Table 17: HALL CALLS Panel

Field	Description
Floor Number	Allows the user to select a floor

Buttons	
	Allows the user to move the car in the UP direction
	Allows the user to move the car in the DOWN direction

Perform the following to initiate a hall call:

- From the HALL CALLS Panel, click on a Floor by selecting the move UP and/or DOWN arrows.
 - The color of the active hall call UP and/or DOWN arrow buttons turn blue.




Figure 37: HALL CALLS Panel ACTIVE HALL CALL

9 SYSTEM

The SYSTEM panel allows the user to choose a system function. Each function provides step-by-step instructions on how to perform backups and updates.

9.1 Software Download

The Software Download subpanel displays detailed instructions to update the system software for Machine Room (MR), Car Top (CT), and Car Operational Panel (COP) boards and for Riser boards.

9.1.1 Software Download Pre-requisites

Minimum Software Requirements for Controller 64i0:

- **Board Version:** SR3032 M3 and higher
- **Shield:** SR2030C
- **Minimum DAD Shield Version:** v1.24 (Note: v1.23 is compatible but operates slower)

Recommended Software Versions for DAD:

- DAD with Local Monitor (LM):
 - **For Raspberry Pi:** lm_rpi_4.1.14_mw_v1.12.15_gui_v1.19.52
 - **For Rock Pi:** lm_rock_4.1.14_mw_v1.12.15_gui_v1.19.52
- DAD with GUI Only:
 - **For Raspberry Pi:** rpi_gui_1.19.52_mw_1.21.15
 - **For Rock Pi:** rock_gui_1.19.52_mw_1.21.15

NOTE: if the above pre-requisites are not met, the software download code cannot be downloaded through the Software Download subpanel. It will need to be downloaded using the Link 2 Programmer.




Figure 38: SYSTEM PANEL - Software Download

The table below lists the description of the SYSTEM Panel - Software Download.

Table 18: SYSTEM Panel - Software Download

Field	Description
INSTRUCTIONS	Displays the instructions on how to start software download
Show details	Displays the download's current status
Buttons	
	Allows the system to signal when it is ready for software download
	Allows the user to choose the car specific file provided by Smartrise (.sbf or .zip)
	Allows the user to upload the selected file
	Allows the user to start the software download process
	Allows the user to select all boards to be updated
	Allows the user to select specific boards to be updated
	Allows the user to finalize the software download process

Perform the following steps to update the software:

1. Remove the WD jumper:

- From the MR and CT boards (when updating the MR, CT, and/or COP boards)
 - On the MR board: the jumper is found on the upper left corner with the initials WD.
 - On the CT/COP board: the jumper is found on the right side of the direction buttons with the initials WD.
- From the Riser board (when updating the Riser board)

2. Turn on:

- DIP 8A on the MR board to download one MR, CT, and/or COP board.
- DIP 5, 6, 7, and 8 on each Riser board to download the selected Riser boards.

3. Watch for a pattern of flashing red and green LEDs on the MCUA and MCUB

- Check the MR board screen for retry and errors (bottom left of the screen during download)

NOTE: the download process must start over if a field in the table below is displayed with 'ABORT'.




Figure 39: MR Board – ERROR

The table below lists the description of the displayed fields during software download.

Table 19: MR board - SOFTWARE DOWNLOAD PROGRESS

Field	Description
Total Packet Counter	Total count packets received by MR-B
Overall Load Progress	Overall load progress – all modules
Module (Board ID)	ID string for the module being loaded (MR-A, MR-B, CT-A, CT-B, RISE, COPA, COPB, DDMA, DDMB, SHLD)
Load Progress %	Load progress – current module
Total S-Records Successfully Loaded	Total number of S-records that were successfully transferred and programmed across all modules
Retry/ Error Causes	<p>Blank Field: No retries or errors.</p> <p>Address – Retry: S-Record addressing error was detected.</p> <p>Checksum – Retry: S-Record checksum error was detected.</p> <p>No S3...– Retry: S-Record package did not start with “S3” sequence record.</p> <p>Overflow – Retry: Load package contains too many records.</p>

	<p>Sequence – Retry: Load package contains missing or out-of-sequence records.</p> <p>Flash Err – Abort: Flash write failed. Retry count = error code</p> <p>Bad Erase – Abort: Download initialization encountered a flash erase problem. Retry count = FFFF</p> <p>Stalled – Abort: MR-B Software Download detected a download stall condition. Retry count = 00FF</p> <p>READY: indicates that MR-B has entered or returned to a state in which it informs the DAD that it is ready to begin a download.</p>
--	--

4. From the SYSTEM Panel - Software Download, click CONTINUE.
 - The system starts checking software download nodes. If no system is detected, the following error is shown.
5. Click on CHOOSE FILE and select the car specific .sbf or .zip file provided by Smartrise and choose whether to import the file ‘from your device’ or ‘from a USB plugged into the DAD’.




Figure 40: SYSTEM Panel - Software Download CHOOSE FILE

6. After selecting the file, click on ‘Upload’.




Figure 41: SYSTEM Panel - Software Download UPLOAD

NOTE: if the file is incompatible with the car, a ‘Warning!’ pop-up will be displayed.




Figure 42: SYSTEM Panel - Software Download CHECKING STATUS




Figure 43: SYSTEM Panel - Software Download WARNING

7. Click on the 'Update' button to begin the software download.




Figure 44: SYSTEM Panel - Software Download UPDATE (.sbf)

NOTE: if the file is uploaded in .zip format, multiple records of .sbf files might be displayed.




Figure 45: SYSTEM Panel - Software Download UPDATE (.zip)

8. To update the MR, CT, and/or COP boards:

- Select the boards you want to update and click UPDATE SELECTED.
- To update all boards, click UPDATE ALL.

admin
Logout

SMARTRISE

MONITORING

FAULTS

ALARMS

PARAMETER

CAR CALLS

HALL CALLS

SYSTEM

Software Download

Backup Param

Restore Param

Update Files

Real Time Clock

System Update

I/O

PARKING

Software Download

INSTRUCTIONS

1a. To update the Machine Room, the Car Top, and the Car Operating Panel boards, disconnect the WD jumper from the MR, CT, and the COP boards.

1b. To update the Riser board, disconnect the WD jumper from the Riser board.

2a. To update the C4 System, turn on DIP A8 – located on the Top Bank on the Machine Room board of the car that needs updating.

NOTE: only one controller can be updated at a time.

2b. To update a particular Riser board, turn on DIPs 5, 6, 7, and 8.

3a. While updating the MR board, wait on processors MCUA and MCUB on the Machine Room board to flash the red and green colored lights. The LCD screen on the MR board should return the TOTAL PACKET # and the state, located on the 4th row from the left, should appear as READY.

3b. While updating the Riser board, wait on LEDs B (green) and FAULT (red) to flash simultaneously.

4. Upload the SBF/ZIP file either from your device or from a USB inserted into DAD.

NOTE: this file should be from the same job uploaded to the GUI/controller.

Click on UPLOAD FILE after selecting file.

5. Click on the UPDATE button to start the software download.

6a. To update certain boards, click on the checkbox below the corresponding board, then click on the UPDATE SELECTED button. To update all boards, click on the UPDATE ALL button.

6b. To update a Riser board, click on the UPDATE ALL button.

7. If the Software Download percentage located at the upper right side of page reaches 100%, a SUCCESS pop-up will appear – meaning the board(s) have been successfully updated.

In case the download was not 100% successful, guidance will be provided - follow the pop-ups on GUI and check the LCD screen state (always wait for the READY state to be able to proceed).

8a. Turn off Machine Room DIP 8A (located on the Top Bank), then cycle power.

8b. Turn off Riser DIPs 5, 6, and 7, then cycle power.

9a. Rewire the WD jumper to the Machine Room and Car Top boards.

9b. Rewire the WD jumper to the Riser boards.

10a. The update should be complete.

The controller software version can be viewed via MAIN MENU -> ABOUT.


NOTE: once the update is complete, re-check that the job name is the same as it was before starting the process.

10b. The update should be complete.

The riser software version can be viewed via STATUS -> RISER BOARD STATUS.


UPDATE ALL
UPDATE SELECTED

Please select the boards to update
Selected boards: 1




Machine Room

MR-B Machine Room B Processor - 0 %
MR-A Machine Room A Processor - 0 %



Car Top

CT-A Car Top A Processor - 0 %
CT-B Car Top B Processor - 0 %



Car Operation Panel

COP-A Car Operation Panel A Processor - 0 %
COP-B Car Operation Panel B Processor - 0 %

Show details ▼

Figure 46: SYSTEM Panel - Software Download UPDATE (MR, CT, COP)

NOTE: the ‘Show Details’ displays the current status of the download.




Figure 47: SYSTEM Panel - Software Download SHOW DETAILS (MR, CT, COP)

The MR board display simultaneously shows the individual and module process of the software download.




Figure 48: MR board - SOFTWARE DOWNLOAD PROGRESS

9. For the Riser board, click on the 'Update' button to begin the software download.




Figure 49: SYSTEM Panel - Software Download RISER UPDATE (.sbf)

10. To update the Riser board, click UPDATE ALL.




Figure 50: SYSTEM Panel - Software Download RISER UPDATE ALL

NOTE: the 'Show Details' displays the current status of the download.




Figure 51: SYSTEM Panel - Software Download RISER SHOW DETAILS

11. When the Software Download percentage located in the top-right corner of the panel reaches 100%, a 'Success' pop up will be displayed.
12. Click on OK.
13. Click on DONE.




Figure 52: SYSTEM Panel - Software Download (MR, CT, COP) SUCCESS




Figure 53: SYSTEM Panel - Software Download RISER SUCCESS





Figure 54: SYSTEM Panel - Software Download DONE

NOTE: when the update is completed, the user will be redirected to the table as shown in the image below, and a green check sign will appear next to 'Update'.



The screenshot shows the 'Software Download' page in the SMARTRISE SYSTEM panel. The page contains a list of instructions for updating various boards and a table showing the status of update jobs.

INSTRUCTIONS

- 1a. To update the Machine Room, the Car Top, and the Car Operating Panel boards, disconnect the WD jumper from the MR, CT, and the COP boards.
- 1b. To update the Riser board, disconnect the WD Jumper from the Riser board.
- 2a. To update the C4 System, turn on DIP A8 – located on the Top Bank on the Machine Room board of the car that needs updating.
NOTE: only one controller can be updated at a time.
- 2b. To update a particular Riser board, turn on DIPs 5, 6, 7, and 8.
- 3a. While updating the MR board, wait on processors MCUA and MCUB on the Machine Room board to flash the red and green colored lights. The LCD screen on the MR board should return the TOTAL PACKET # and the state, located on the 4th row from the left, should appear as READY.
- 3b. While updating the Riser board, wait on LEDs B (green) and FAULT (red) to flash simultaneously.
4. Upload the SBF/ZIP file either from your device or from a USB inserted into DAD.
NOTE: this file should be from the same job uploaded to the GUI/controller.
Click on UPLOAD FILE after selecting file.
5. Click on the UPDATE button to start the software download.
- 6a. To update certain boards, click on the checkbox below the corresponding board, then click on the UPDATE SELECTED button. To update all boards, click on the UPDATE ALL button.
- 6b. To update a Riser board, click on the UPDATE ALL button.
7. If the Software Download percentage located at the upper right side of page reaches 100%, a SUCCESS pop-up will appear – meaning the board(s) have been successfully updated. In case the download was not 100% successful, guidance will be provided - follow the pop-ups on GUI and check the LCD screen state (always wait for the READY state to be able to proceed).
- 8a. Turn off Machine Room DIP 8A (located on the Top Bank), then cycle power.
- 8b. Turn off Riser DIPs 5, 6, and 7, then cycle power.
- 9a. Rewire the WD jumper to the Machine Room and Car Top boards.
- 9b. Rewire the WD jumper to the Riser boards.
- 10a. The update should be complete.
The controller software version can be viewed via MAIN MENU -> ABOUT.
NOTE: once the update is complete, re-check that the job name is the same as it was before starting the process.
- 10b. The update should be complete.
The riser software version can be viewed via STATUS -> RISER BOARD STATUS.

#	File Name	Last Update (OTA)	Status	Actions
0	Car2_JobNameX_V01_02_65g0.sbf	N/A	Car 2 Not Ready	<button>Update</button>
1	Car3_JobNameX_V01_02_65g0.sbf	N/A	Car 3 Not Ready	<button>Update</button>
2	Car1_JobNameX_V01_02_65g0.sbf	Tue Mar 5 04:29:23 EST 2024	Car 1 Ready	<button>Update</button>

Figure 55: SYSTEM Panel - Software Download Update Completed

14. Turn off:

- DIP 8A on the MR board.
- DIPs 5, 6, and 7 on each Riser board.

15. Put the WD jumper back:

- To the MR and CT boards.
- To the Riser boards.

16. The update is now complete.

NOTE I: in case the GUI is unable to establish a connection with the DAD unit (due to a WebSocket issue for example), a Warning message is displayed giving you the option to either 'Restart Containers' or 'Reload Page'.

NOTE II: Before attempting another download, wait until the MR LCD displays 'READY'. If the download process starts too soon, it will fail again.




Figure 56: SYSTEM Panel – Software Download WARNING

9.2 Backup Param

The Backup Param subpanel allows the user to back up the parameters for a selected car. The downloaded file contains all the parameters and their respective values.




Figure 57: SYSTEM Panel - Backup Param

NOTE: if the car is offline, the START BACKUP button won't be displayed.




Figure 58: SYSTEM Panel - Backup Param CAR OFFLINE

The table below lists the description of the SYSTEM Panel - Backup Param.

Table 20: SYSTEM Panel - Backup Param

Field	Description
CAR 1 2	Allows the user to select the car label
INSTRUCTIONS	Displays the instructions on how to back up the parameters
Buttons	
START BACKUP	Allows the user to start the backup
DOWNLOAD BACKUP	Allows the user to save the parameter file to the specified location

Perform the following steps to backup parameters for a particular car:

1. From the SYSTEM Panel - Backup Param, select the car label of that car and click on START BACKUP.
2. The application starts copying the parameters of the selected car and shows a progress percentage on the screen.




Figure 59: SYSTEM Panel - Backup Param START BACKUP

- When complete, click DOWNLOAD BACKUP.

NOTE: the "backup-car[label].spf" is downloaded into the Downloads folder by default. The user can also select the location of the download.




Figure 60: SYSTEM Panel - Backup Param DOWNLOAD BACKUP

9.3 Restore Param

The Restore Param subpanel allows the user to overwrite the selected car’s parameters using the selected file. The Restore Parameter is basically derived from the Backup Parameter.




Figure 61: SYSTEM Panel - Restore Param

The table below lists the description of the SYSTEM Panel - Restore Param.

Table 21: SYSTEM Panel - Restore Param

Field	Description
CAR 1 2	Allows the user to select the car label
INSTRUCTIONS	Displays the instructions on how to restore the parameters
Buttons	
CHOOSE FILE	Allows the user to choose the parameter file
UPLOAD FILE	Allows the user to upload the parameter file
START RESTORE	Allows the user to start the restore parameter process

Perform the following steps to restore the parameters for a particular car:

1. Turn on DIP A4.
2. From the SYSTEM Panel - Restore Param, select the car label and click CHOOSE FILE.
3. From the Downloads folder, select the “backup_car[label].spf” file.

4. Set the MR board to Inspection Mode.
5. Click on UPLOAD FILE.




Figure 62: SYSTEM Panel - Restore Param UPLOAD FILE

6. Click on START RESTORE.




Figure 63: SYSTEM Panel - Restore Param START RESTORE

NOTE: if the MR board is not in Inspection Mode, a Machine Room Board Inspection Mode Warning is displayed and the process ends.




Figure 64: SYSTEM Panel - Restore Param WARNING

7. A percentage number is displayed. The parameters are restored when the screen displays 100%.




Figure 65: SYSTEM Panel - Restore Param RESTORE PROGRESS




Figure 66: SYSTEM Panel - Restore Param RESTORE COMPLETED I




Figure 67: SYSTEM Panel - Restore Param RESTORE COMPLETED II

8. Power cycle the unit and set the MR to Normal mode.

9.4 Update Files

System updates are carried out by selecting a file and downloading it to the system.

9.4.1 UPDATE FILES

The UPDATE FILES subpanel allows the user to update the files list. This list includes any or a combination of the following:

1. **FAULTS List:** consists of FAULTS IDs and descriptions as displayed on the FAULTS Panel.
2. **ALARMS LIST:** consists of ALARM IDs and DESCRIPTIONS as displayed on the ALARMS Panel.
3. **PARAMETER LIST:** consists of PARAMETER TYPES, INDEX, and NAMES.
4. **I/O LIST:** consists of I/O NAMES.




Figure 68: SYSTEM Panel - Update Files [FILES]

The table below lists the description of the SYSTEM Panel - Update Files [FILES].

Table 22: SYSTEM Panel - Update Files [FILES]

Field	Description
INSTRUCTIONS	Displays the instructions on how to restore the parameters
Buttons	
	Allows the user to select the package file from their local device or from a plugged USB drive into DAD
	Allows the user to upload and update the file list on the system

Perform the following steps to update the files list:

1. From the SYSTEM Panel - Update Files - FILES, select the .zip package file from your device or from a USB plugged into the DAD.




Figure 69: SYSTEM Panel - Update Files [FILES: CHOOSE FILE (From USB inserted into DAD)]

2. After selection the file, click on 'Upload & Update'.




Figure 70: SYSTEM Panel - Update Files [FILES: UPLOAD & UPDATE (From your Device)]




Figure 71: SYSTEM Panel - Update Files [FILES: UPLOAD & UPDATE (From USB inserted into DAD)]

3. The application will start the update process and a loading message is displayed.




Figure 72: SYSTEM Panel - Update Files [FILES: LOADING]

4. When the update is complete, a success popup is displayed. Click OK.




Figure 73: SYSTEM Panel - Update Files [FILES: SUCCESS]

- The list of files uploaded to the system is displayed on the screen along with the date and time of the update.




Figure 74: SYSTEM Panel - Update Files [FILES: UPLOADED LIST OF FILES]

NOTE: in case of an invalid file, an error message will be displayed.




Figure 75: SYSTEM Panel - Update Files [FILES: INVALID FILE]

9.4.2 UPDATE CONFIG

The UPDATE CONFIG subpanel allows the user to choose a job specific configuration file to update the entire application to that job’s specifications.

The purpose of CONFIG is to streamline the process of setting up a C4 DAD with job specific data.




Figure 76: SYSTEM Panel - Update Files [CONFIG]

The table below lists the description of the SYSTEM Panel - Update Files [CONFIG].

Table 23: SYSTEM Panel - Update Files [CONFIG]

Field	Description
INSTRUCTIONS	Displays the instructions on how to upload configuration files
Buttons	
	Allows the user to select the configuration file to upload
	Allows the user to upload the configuration file to the DAD unit
	Allows the user to download the configuration file to the C4 application

Perform the following steps to update the config file:

1. From the SYSTEM Panel - Update Files - CONFIG, click CHOOSE FILE.
2. Select the SYNC CONFIG GILE (config*.h) to update a specific job.
3. Click UPDATE CONFIG.
 - The system begins to upload the new configuration file.




Figure 77: SYSTEM Panel - Update Files [CONFIG: UPDATE CONFIG]

4. Click SYNC NEW CONFIG to download the configuration file to the C4 application.




Figure 78: SYSTEM Panel - Update Files [CONFIG: SYNC NEW CONFIG]

5. A 'Success' popup is displayed.




Figure 79: SYSTEM Panel - Update Files [CONFIG: SUCCESS]

NOTE: the user will be automatically redirected to the Restart Container page. Then once the 90 second count is completed, the user will then be redirected to the Monitoring page.




Figure 80: SYSTEM– Update Config SYSTEM RELOAD

9.5 Real Time Clock

The Real Time Clock subpanel displays the real date and time obtained from the controller. After changing the date and/or time, the system performs a reload session and return to the MONIROTING Panel.





Figure 81: SYSTEM Panel - Real Time Clock

The table below lists the description of the SYSTEM Panel - Real Time Clock.

Table 24: SYSTEM Panel - Real Time Clock

Field	Description
SET NEW DATE – MM	Allows the user to select the real time MONTH
SET NEW DATE – DD	Allows the user to select the real time DAY
SET NEW DATE – YYYY	Allows the user to select the real time YEAR
SET NEW TIME – HR	Allows the user to select the real time HOUR
SET NEW TIME – MIN	Allows the user to select the real time MINUTE
SET NEW TIME – TIME ZONE	Allows the user to select the location’s time zone
Buttons	
	Allows the user to save the real DATE & TIME

Perform the following steps to update the real time clock:

- From the SYSTEM Panel - Real Time Clock, select the current date and time from each dropdown list.
 - NOTE:** the time is entered in military time format.
- Click SAVE DATE & TIME to save the real time.
 - The system reloads and then returns to the MONIROTING Panel.




Figure 82: SYSTEM Panel - Real Time Clock SYSTEM RELOAD




Figure 83: MONIROTING Panel Landing Page

9.6 System Update

The System Update subpanel allows the user to update the software version for the GUI application on the DAD Unit. This update is carried out by selecting a file and downloading it to the system.




Figure 84: SYSTEM Panel - System Update

The table below lists the description of the SYSTEM Panel - System Update.

Table 25: SYSTEM Panel - System Update

Field	Description
CURRENT VERSIONS	Displays the current versions of C4 Middleware, C4 GUI, and C4 System Manager
Update the C4 DAD	Allows the user to update the system from the local device or from USB drive
Buttons	
	Allows the user to back up the current software version
	Allows the user to choose the system update file

Perform the following steps to update the system:

1. From the SYSTEM Panel - System Update, click CHOOSE FILE and select the system update file and choose whether to import the file ‘from your device’ or ‘from a USB plugged into the DAD’.
2. Proceed with the guided steps displayed on the subpanel.

10 I/O

The I/O Panel allows the user to add, change, remove, or move UNFIXED inputs and outputs.

Fixed inputs and outputs cannot be changed due to safety concerns. If additional feature, or moving an input or output, is required, any UNUSED input or output can be assigned a feature.

Inputs are assigned to the 500s and outputs to the 600s.

10.1 Machine Room

On the MR board, each input and output is defined.




Figure 85: I/O Panel - Machine Room

The table below lists the description of the I/O Panel - Machine Room.

Table 26: I/O Panel - Machine Room

Field	Description
CAR 1 2	Allows the user to select the car label
INPUTS	
501-508	Allows the user to select the type of input to the MR board ports 501-508

OUTPUTS	
601-608	Allows the user to select the type of output from the MR board ports 601-608
Buttons	
	Allows the user to save the selected type of input to MR board ports 501-508 or the selected type of output from the MR board ports 601-608
	Allows the user to save all input and output changes to the MR board ports 501-508 and from the MR board ports 601-608

NOTE: inputs/outputs can be saved separately by clicking SAVE next to each type of input/output

Perform the following steps to update the Machine Room Input/Output for a particular car:

1. Turn on DIP A4.
2. From the I/O Panel - Machine Room, select the car label.
3. Click on each dropdown list and select the type of input and/or output.
4. Click SAVE or SAVE CHANGES.
 - A green save tag with a checkmark is displayed.




Figure 86: I/O Panel - Machine Room SAVE

10.2 Cartop

On the Cartop board, each input and output is defined.







Figure 87: I/O Panel – Cartop

The table below lists the description of the I/O Panel - Cartop.

Table 27: I/O Panel - Cartop

Field	Description
	Allows the user to select the car label
INPUTS	
501-516	Allows the user to select the type of input to the Cartop board ports 501-516
OUTPUTS	
601-616	Allows the user to select the type of output from the Cartop board ports 601-616
Buttons	
	Allows the user to save the selected type of input to Cartop board ports 501-516 or the selected type of output from the Cartop board ports 601-616
	Allows the user to save all input and output changes to the Cartop board ports 501-516 and from the Cartop board ports 601-616

Perform the following steps to update the Cartop Input/Output for a particular car:

1. Turn on DIP A4.
2. From the I/O Panel - Cartop, select the car label.
3. Click on each dropdown list and select the type of input and/or output.
4. Click SAVE or SAVE CHANGES.
 - A green save tag with a checkmark is displayed.




Figure 88: I/O Panel - Cartop SAVE

10.3 COP

On the COP board, each input and output is defined.







Figure 89: I/O Panel - COP

The table below lists the description of the I/O Panel - COP.

Table 28: I/O Panel - COP

Field	Description
-------	-------------

	Allows the user to select the car label
INPUTS	
501-516	Allows the user to select the type of input to the COP board ports 501-516
OUTPUTS	
601-616	Allows the user to select the type of output from the COP board ports 601-616
Buttons	
	Allows the user to save the selected type of input to COP board ports 501-516 or the selected type of output from the COP board ports 601-616
	Allows the user to save all input and output changes to the COP board ports 501-516 and from the COP board ports 601-616

Perform the following steps to update the Machine Room Input/Output for a particular car:

1. Turn on DIP A4.
2. From the I/O Panel - COP, select the car label.
3. Click on each dropdown list and select the type of input and/or output.
4. Click SAVE or SAVE CHANGES.
 - A green save tag with a checkmark is displayed.




Figure 90: I/O Panel – COP SAVE

10.4 Risers

The Riser board can be configured for fire service, emergency power, and hall network connections.

Up to four Riser boards can be used within the system.




Figure 91: I/O Panel – Risers

The table below lists the description of the I/O Panel - Risers.

Table 29: I/O Panel - Risers

Field	Description
CAR 1 2	Allows the user to select the car label
INPUTS	
501-508	Allows the user to select the type of input to the Riser board ports 501-508
OUTPUTS	
601-608	Allows the user to select the type of output from the Riser board ports 601-608
Buttons	

	Allows the user to save the selected type of input to Riser board ports 501-508 or the selected type of output from the Riser board ports 601-608
	Allows the user to save all input and output changes to the Riser board ports 501-508 and from the Riser board ports 601-608

Perform the following steps to update the Riser Input/Output for a particular car:

1. Turn on DIP A4.
2. From the I/O Panel - Riser, select the car label.
3. Click on each dropdown list and select the type of input and/or output.
4. Click SAVE or SAVE CHANGES.
 - A green save tag with a checkmark is displayed.




Figure 92: I/O Panel - Risers SAVE

10.5 Expansions

Expansion boards are additional boards used to add inputs and outputs. Each expansion board has 8 adjustable inputs and 8 adjustable outputs.

Up to 40 expansion boards can be used within the system.

Once the user selects the Expansion board from the dropdown; the screen below is displayed:






Figure 93: I/O Panel – Expansions

The table below lists the description of the I/O Panel - Expansions.

Table 30: I/O Panel - Expansions

Field	Description
Expansion 1 ▾	Allows the user to select an Expansion board
INPUTS	
501-508	Allows the user to select the type of input to the Expansion board ports 501-508
OUTPUTS	
601-608	Allows the user to select the type of output from the Expansion board ports 601-608
Buttons	

	Allows the user to save the selected type of input to Expansion board ports 501-508 or the selected type of output from the Expansion board ports 601-608
	Allows the user to save all input and output changes to the Expansion board ports 501-508 and from the Expansion board ports 601-608

Perform the following steps to update the Expansion Input/Output for a particular car:

1. Turn on DIP A4.
2. From the I/O Panel - Expansion, click on the dropdown list and select the Expansion board to which inputs and outputs will be assigned.




Figure 94: I/O Panel - Expansions SELECT EXPANSION BOARD

1. Click on each dropdown list and select the type of input and/or output.
2. Click SAVE or SAVE CHANGES.
 - A green save tag with a checkmark is displayed.

NOTE: This process must be repeated for each expansion board.




Figure 95: I/O Panel – Expansions SAVE

11 PARKING

The PARKING panel allows the user to move an idle car/group of cars to a designated floor. The purpose of PARKING is to reduce the amount of time it takes to service busy floors.

For example: when a car has finished all its requests, it will return to the parking floor and remain there until another request is made.

11.1 Calendar






The Calendar subpanel displays where a car/ group of cars will park according to the rules for a specific time and day of the week. Rules also specify whether the doors will open or remain closed.



Figure 96: PARKING Panel - Calendar

The table below lists the description of the PARKING Panel - Calendar.

Table 31: PARKING Panel - Calendar

Field	Description
Day & Time	Displays the parking rules for a car/ group of cars for a specific day and time
Buttons	
 Car Specific Rule	Indicates a car-specific parking rule for specific days and times
 Any Car Rule	Indicates a floor-specific parking rule for specific days and times
 Historical Parking	Indicates historical data of parking rules for all cars for specific days and times
 Park with door open	Indicates that the door state for the applied rule will be open (i.e., the car will park with open doors)
 Park with doors closed	Indicates that the door state for the applied rule will be closed (i.e., the car will park with closed doors)

11.2 Rules

The Rules subpanel allows the user to create parking rules.

Parking rules are created to instruct a car(s) to park on certain floors during periods of high traffic, for example. Doors can either be set to open or remain closed upon parking.




Figure 97: PARKING Panel




Figure 98: PARKING Panel - Rules

The table below lists the description of the PARKING Panel - Rules.

Table 32: PARKING Panel - Rules

Field	Description
List of rules	Displays a list of all parking rules
Set rule	Describes the created parking rule
Buttons	
	Allows the user to create a parking rule
	Allows the user to edit a parking rule
	Allows the user to delete a parking rule
activate	Allows the user to activate a parking rule by sliding the button to the left
deactivate	Allows the user to deactivate a parking rule by sliding the button to the right

Perform the following steps to create Parking Rules:

1. From the PARKING Panel - Rules, click on CREATE RULE.
2. Is the rule created for a specific car or floor:
 - i. Car-specific: go to Step 3.

- ii. Floor-specific: go to Step 5.
- 3. The CREATE RULE – Car-specific pop-up is displayed.




Figure 99: PARKING Panel – Rules CREATE RULE [Car-specific popup]

- 4. Fill the required fields and click ‘Create Rule’.
 - The rule is displayed on PARKING Panel – Rules.
- 5. The CREATE RULE – Floor-specific pop-up will be displayed.






Figure 100: PARKING Panel - Rules: CREATE RULE [Floor-specific popup]

6. Fill the required fields and click ‘Create Rule’.
 - The rule is displayed on PARKING Panel – Rules.

The table below lists the description of the CREATE RULE pop-up.

Table 33: PARKING Panel - Rules: CREATE RULE popup

Field	Description
Name	Allows the user to enter the rule’s name
Day	Allows the user to enter to rule’s effective day
Start	Allows the user to select the rule’s start time
End	Allows the user to select the rule’s end time
Door	Allows the user to select whether the car door is open or closed
Car specific	Allows the user to set a rule for a specific car to park on a specific floor
Floor specific	Allows the user to set a rule for any available car(s) to park on a specific floor
Priority	Allows the user to select the rule’s priority. <i>Priority only applied to floor-specific rules</i>
Car [X]	Allows the user to select the designated floor for each Car Label from the dropdown to which this rule is set for
Car #	Allows the user to select the number of cars to which this rule is set for
Buttons	
	Allows the user to save the parking rule
	Allows the user to close the CREATE RULE popup without saving the parking rule

12 DYNAMIC SECURITY

The DYNAMIC SECURITY panel allows the user to secure a door or an entry point. The purpose of DYNAMIC SECURITY is to help individuals access cars that are “open” to them. When active for a pre-set period of time, passengers cannot access certain floors/doors/cars depending on the type of security activated.

12.1 Rules

Security Rules are created to lock floors/doors per car or all cars for a specific time and day of the week.




Figure 101: DYNAMIC SECURITY Panel




Figure 102: DYNAMIC SECURITY Panel – Rules (I)




Figure 103: DYNAMIC SECURITY Panel – Rules (II)

The table below lists the description of the DYNAMIC SECURITY Panel - Rules.

Table 34: DYNAMIC SECURITY Panel - Rules

Field	Description
List of Security Rules	Displays a list of all security rules
	Represents a non-current rule
	Represents a current rule
Buttons	

	Allows the user to create a security rule
	Allows the user to edit a security rule
	Allows the user to delete a security rule
	Allows the user to activate a security rule by sliding the button to the left
	Allows the user to deactivate a security rule by sliding the button to the right

Perform the following steps to create security rules:

1. From the DYNAMIC SECURITY Panel - Rules, click on CREATE RULE.
2. The CREATE RULE popup is displayed.




Figure 104: DYNAMIC SECURITY – Rules CREATE RULE popup

3. Fill the required fields and click ‘Create Rule’.
 - The rule is displayed on the DYNAMIC SECURITY Panel – Rules

NOTE: the Rule is created by default in a deactivated state.

The table below lists the description of the CREATE RULE popup.

Table 35: DYNAMIC SECURITY Panel - Rules CREATE RULE popup

Field	Description
Rule Name	Allows the user to enter the rule’s name

Day	Allows the user to enter to rule’s effective day
Start Time	Allows the user to select the rule’s start time
End Time	Allows the user to select the rule’s end time
Hall Call Floors	Allows the user to select which floor and corresponding door the rule is applied to
Car Call Floors	Allows the user to select, for a specific car, which floor and corresponding door the rule is applied to
Buttons	
	Allows the user to save the security rule
	Allows the user to close the CREATE RULE popup without saving the security rule

- To make the Rule active, the user must first ensure that the date and time on the desired rule matches the current date and time on the DAD unit and then “activate” the rule.




Figure 105: Activating a Rule




Figure 106: Secured Floors Display [Hall Calls]




Figure 107: Secured Floors Display [Car Calls]

NOTE: for DYNAMIC SECURITY, the following parameters should have the following values:

- 235 (Disable Virtual Input) OFF
- 1-257 (Enable Remote Security) ON
- 1-173 (Disable DOB Secured FLR) ON
- 1-138 (Enable Hall Security) ON

13 SECURITY

The SECURITY panel allows the user to secure a floor or an entry point. Unauthorized personnel cannot access these secured floors.

NOTE: “R” indicates rear doors.




Figure 108: SECURITY Panel

Perform the following steps to secure a floor for a particular car:

1. From the SECURITY Panel, select the car label.

2. Click on the floor number.

- The color of the call button turns blue when the user locks the floor and turns to default dark grey when the user unlocks the floor.

NOTE: the user can select specific floors to lock/unlock or the user can lock/unlock all floors.




Figure 109: SECURITY Panel Active

14 REPLAY

The REPLAY panel allows the user to display the state of the car before, during, and after a fault/alarm event occurs.

NOTE I: if the total time range of an event exceeds 90 seconds, the REPLAY will create multiple events for the same case.

NOTE II: in order for the events to be produced, the user should have selected the Faults and/or Alarms numbers presented under the Configuration subpanel.

14.1 List & Configuration

The List subpanel displays the events.

The user can:

- i. click on CLEAR EVENTS to clear *all* events.
- ii. filter the events by date range.




Figure 110: REPLAY Panel – List [Default: no events]

The Configuration subpanel displays the Fault and/or Alarms. The user can select which Fault/Alarm to track.

NOTE: the user can select one or multiple Faults/Alarms to track.




Figure 111: REPLAY Panel - Configuration [Faults: default state]




Figure 112: REPLAY Panel- Configuration [Alarms: default state]

The following procedure describes how to employ the Replay Feature:

1. Under the Configuration subpanel, select the desired Fault(s)/Alarm(s) to track.




Figure 113: REPLAY Panel- Configuration [Faults: selected state]




Figure 114: REPLAY Panel- Configuration [Alarms: selected state]

- Click on the SAVE CHANGES button - a 'Success' pop up will be displayed.




Figure 115: REPLAY Panel- Configuration [Success popup]

3. Click on the OK button.

NOTE: the user will be automatically redirected to the Restart Container page. Then, once the 90 second count is completed, the user will then be redirected to the Monitoring page.




Figure 116: REPLAY Panel – Configuration SYSTEM RELOAD

4. To track the selected Fault(s)/Alarm(s), click on the List subpanel.

NOTE: if any Fault(s)/Alarm(s) occurred outside the selected event, they will be displayed on the graph but not on the EVENTS list.




Figure 117: REPLAY Panel - List [Event tracking]

NOTE I: the user has the option to select which type of event (Car Position, Car Speed, Faults, or Alarms) desired to track.




Figure 118: REPLAY Panel – List [Filter applied: Faults]




Figure 119: REPLAY Panel – List [Filter applied: Alarms]




Figure 120: REPLAY Panel – List [Filter applied: Car position]




Figure 121: REPLAY Panel – List [Filter applied: Car speed]

NOTE II: hover the cursor over the graphs to view the car position and car speed at a specific instant.




Figure 122: REPLAY Panel - List [Car position and car speed]

- Click on any point on the graph to view the Car Data at a specific instant.

NOTE: the data displayed will be that of the Floor Label, Position, Car Speed, Motion, Inputs & Outputs states.




Figure 123: REPLAY Panel - List [Car data popup]

6. To view the Inputs status, click on All Inputs.




Figure 124: REPLAY Panel - List [All inputs statuses]

7. To view the Outputs status, click on All Outputs.




Figure 125: REPLAY Panel - List [All outputs statuses]

NOTE: the user can zoom-in to view the events at shorter time intervals.




Figure 126: REPLAY Panel – List [Shorter time intervals]

- To download and view the graph in full screen mode, click on the hamburger icon and select the download file type required.




Figure 127: REPLAY Panel- List [Download graph]

NOTE: for a group of cars, a single event, for a specific time interval, can record the same/different Fault(s)/Alarm(s) that have occurred on the cars.




Figure 128: REPLAY Panel – List [EVENTS: Multiple cars Q8]




Figure 129: REPLAY Panel – List [EVENTS: Multiple cars Q5]

15 USERS

The USERS panel permits the creation of a new user, the ability to change the password of the current logged-in user, and to display the list of users available on the system.




Figure 130: USERS Panel - Create User




Figure 131: USERS Panel - Create User USERNAME VALIDATION




Figure 132: USERS Panel - Create User PASSWORD VALIDATION




Figure 133: USERS Panel - All Users




Figure 134: USERS Panel - Change Password

16 ABOUT

The ABOUT Panel displays the current software and validity of system files and database tables.




Figure 135: ABOUT Panel: TRACTION JOB




Figure 136: ABOUT Panel: HYDRO JOB

The table below lists the description of the ABOUT Panel.

Table 36: ABOUT Panel

Field	Description
SYSTEM VERSIONS	Displays current System Version
SYSTEM FILES	Displays validity of files and databases
SYSTEM INFO	Displays the start and end of the sync process along with the Wi-Fi SSID

List of Abbreviations

COP	Car Operating Panel
CT	Car Top
DAD	Data Acquisition Device
GUI	Graphical User Interface
HB	Heartbeat
LM	Local Monitor
MR	Machine Room
PI	Position Indicator