



# SMARTRISE

MADE STRONG

## INSTALLATION MANUAL

for

## CONTACTORS



# Contactor Replacement Procedure

---

The contactor is mounted on the lower rail. Use the following procedure to replace the contactor:

1. Turn off Main Disconnect Power.
2. Label and remove the wiring going to the old contactor and the AUX contactor attached to it.
3. Remove the contactor from the mounting rail.
4. FIGURE 1: Remove the AUX contactor from the old contactor and install it on the new contactor. Disregard this step if a new AUX contactor was included with new contactor. In this case, install the new AUX contactor.
5. FIGURE 2: Remove the Surge Suppressor from the A1 / A2 connectors on the contactor and install it on the new contactor.
6. Install the contactor on the mounting rail.
7. Re-install the wiring removed in Step 2.
8. Turn on Main Disconnect Power.

***The replacement of the contactor is now complete.***

Figure 1




Figure 2

