


C4

ELEVATOR CONTROL SYSTEM



C4 LOCAL MONITORING

Smartrise's C4 Local Monitoring uses the technology inside every Smartrise elevator controller to automatically collect detailed information about minute-to-minute operations, system events, faults, and operating statuses. More than just a passive database tool, C4 Local Monitoring can be easily configured to automatically contact your workstation whenever a problem arises.

C4 Local Monitoring is a program that communicates with elevators and group dispatchers through Ethernet and TCP/IP. The Server resides on the Local Area Network (LAN) with the elevator equipment. You can log on to the Server using any workstation running the Smartrise Client application.

Once connected, all information in the current log is immediately available. Select from preconfigured reports, pick start and end times, and information from the database is presented in a simple, precise format.

C4 Local Monitoring allows you to save collected information to a database. C4 Monitoring Interface hardware provided by Smartrise makes reports available 24/7 at any location in the building via browser.

BENEFITS

- Collect, store, and recall system information for performance analysis or other needs
- Automatically alert workstation
- Retain records of building elevator traffic
- View or print report screens
- Save historical data to XML files
- Log maintenance activity

PRECONFIGURED REPORTS

- Hall Call Performance
- Hall Call Analysis
- Traffic Analysis
- Hall Call Log
- Car Call Log
- Event Log
- Percent In Service

Please see reverse side for additional information.



SMARTRISE

Phone: 469-678-8000


Address: 1235 N. Union Bower Rd
Irving, TX 75061

Website: SMARTRISE.US


C4

ELEVATOR CONTROL SYSTEM


C4 Local Monitoring allows you to log maintenance activity, providing a history of faults and repairs.



C4 Local Monitoring automatically collects data needed to track the performance of your elevator systems and to monitor elevator traffic over a certain period.



The Hall Call Log permits the user to analyze hall call wait times, allowing you to filter the information by date, time, car number, initiating call floor, riser, travel direction, door location, and minimum/maximum wait times. Administrators can flag and highlight selected wait time criteria.



The Hall Call Analysis Report displays all hall calls placed and groups wait times according to user criteria.

Contact our Sales Department at sales@smartrise.us to order or for more information.

Phone: 469-678-8000

Address: 1235 N. Union Bower Rd
Irving, TX 75061

Website: SMARTRISE.US